

20" LCD Multi-Media Digital Poster

V20A1



▶ Features:

- > Display HD pictures in a loop—replace traditional posters
- > Display flash programs — convert flash format to video format
- > Powerful play list editor— manage start time, duration and effects
- > Easy to copy files through USB port or memory cards
- > Corresponding JPG and MP3 files match intellectually— create attractive sound effect
- > Modern appearance — absolute focus of attention
- > Easy to install — no damage to the wall
- > Display rolling messages — an editor used to edit messages
- > Powerful timer— completely free of care


Focus on Digital Media Display Offer Total Solution & One-stop Service

▶ Display Parameters:


Model	V20A1
Display	20 inch
Resolution	1600 x 1200
Size(mm)	485 (H) x 587(V) x 33(D)
Diaplay area(mm)	408(H) x 306(V)
Brightness	300 cd/m ² max.
Ratio	4:3
Contrast ratio	600:1 typ.
Input voltage	AC110~240V(50Hz~60Hz)
Working temp	0 C° to 50 C°
Power	60W
Media format	MPEG1(VCD),MPEG2(DVD),MPEG4,MP3,JPEG
Memory	64MB—12GB
Audio	2W,8Ω
Import file	USB
Default start mode	JPEG,MPEG,MP3
Box detail(mm)	707 x 618 x 164
Net weight	11.5kg/pcs
Gross weight	13.5kg/pcs
Package	Remote、AC power line、user's manual、key、Wall-mount

▶ Outline


Front:




Back:



Right:



Bottom:



▶ Functions

1) USB import files to CF card


The files is copied to the memory (built-in CF card) of the product by USB(the previous files in the memory will be deleted) with hot swapping acceptable.

- 1.Copy the files to the USB
- 2.Power on and unlock the product to insert the USB
- 3.The files in the USB is copied to the built-in memory card automatically
4. Thefiles will be shown automatically and circularly on the screen after thefiles have been copied

▶ Edit play list:

Use a software named “XmlEditor” to edit play lists. In a play list, set up a group and add items into it. Set a Start Time and an End Time for each group. Change the Switch mode and Interval time of JPG files and change the Number of repeat and Volume of MPEG files.

Set up a folder named “Loop” and copy the play list and all related JPG, MPEG and MP3 files into “Loop”. Insert the card into the display and it will display the files automatically.




The screenshot shows the XmlEditor software interface with a table of play list items. The table has columns for Element, File, Start time, End time, Interval, Switch mode, The number of repeat, Volume, and Text. The data is as follows:

Element	File	Start time	End time	Interval	Switch mode	The number of repeat	Volume	Text
Goodview		10:20	11:05					
1	1.jpg			3	1: Left to Right			Focus on China AD AND Sign Industry--Shanghai, APPPE...
2	2.jpg			5	2: Right to Left			
3	3.jpg			7	6: Top to Bottom			
4	CECT手机15C.mpg					3	20	
Goodview-1		11:05	12:30					
new-1	APP行业-5.mpg					4	25	'City of Eternal Spring' hosts successful torch relay
new-2	APP行业-30.mpg					5	30	
new-3	25.jpg			2	10: Cross Fade			
new-4	24.jpg			6	1: Left to Right			

Play List Main Page

▶ Rolling message:

While editing a play list, please edit the content under the item of text which will be shown at the bottom of display.



▶ Applications:

Business Institution: department store, train store, super mart, exclusive store, grand hotel, restaurant, travel agency, drug store, etc.

Financial Institution: bank, stock market, fund exchange center, insurance company, mortgage stores, etc.

Public Service: hospital, school, telecom hall, post office, etc.

Public Place: subway, airport, bookstore, park, exhibition center, stadium, museum, conference center, tickets agency, HR market, lottery center, etc.

Real Estate: apartment, villa, business building, show room, real-estate trade center, etc

Entertainment Place: cinema, gym, holiday inn, club, massage room, bar, net bar, beauty parlor, golf, etc.

